


Golfshot Plus

iOS VERSION 5.1+



CONTENTS

Home Screen

Awards

Preview

Rounds

Settings

Shot Tracking

Statistics

Select Facility

Round Menu

Handicap Index®

Round Setup

Hole Averages

Course Preview

Hole List

Scoring

GolfNow Tee Times

GPS Screen

Maximizing Battery Life

Apple Watch®

Golfscape

Support Resources

Golfplan

Zoom


HOME SCREEN

Play Golf: Tap “Start Round” to begin a round with Golfshot. To start a round at a different facility, tap ‘Select Different Facility’.

For Pro members, you can select a facility and begin your round.

Free members will be prompted to upgrade to Pro Membership, start or continue the 7-day Pro trial, or continue with Free Edition.

In the middle of a round, or if the previous round has not ended, this button will change to “Resume Round”. To end a round in progress, tap “End Round” from the home screen. You must end a current round before you can start another.



HOME SCREEN


Statistics: View all your progress and statistics.

Rounds: All your round information and history.

Course Preview: Visualize your round before you play with 3D previews of the entire course.

Handicap Index®: Upgrade to Pro and link your GHIN number for effortless scoring and posting management.

News: Get the latest news from the golf industry in our news-feed.




HOME SCREEN

Awards: Earn and share awards showing improvement of your game.

Tee Times: Search, book, and enjoy up to 80% off GolfNow tee times.


Videos: Get personalized videos from the world's most sought-after coaches.

Settings: Customize your account, GPS, equipment, and course settings.




ROUNDS

Displays all of the rounds you've played with Golfshot. Shows the round and net score, GIR and fairway percentage, and putting averages. Use the search option to locate rounds at a particular course. Tap on a round for options like viewing the scorecard, tracked shots, and editing scores.



STATISTICS

Analyze your Fairways, Greens in Regulation, Putting, Pars, Scoring, and Clubs statistics. Tap on a category to see it in more detail as it pertains to your specific rounds played.




HANDICAP INDEX®

Golfshot Pro members can link any existing GHIN® Number to Golfshot. You can post your scores here or at the end of a round to your Handicap Index® once your GHIN® Number is linked.


View all your rounds posted to your Handicap Index®, post existing rounds recorded in Golfshot, or post a round manually by tapping the plus icon in the upper right hand corner.

Note: Handicap Index® only applies for approved courses in the United States.




COURSE PREVIEW

Utilize the Course Preview feature to gain a new perspective of the course. Take advantage of the full course 3D flyovers to prepare for your rounds and plan out each hole.



GOLFNOW TEE TIMES

You can search and book GolfNow tee times with exclusive discounts for Golfshot members. Easily search for tee times in your area or at specific golf courses, and collect favorites to quickly book and invite friends to play.



APPLE WATCH®

Sync your iPhone to your Apple Watch and enjoy Golfshot's features on your wrist. Open the Apple Watch app on your iPhone 5 or newer and select "Start Pairing" to connect your Apple Watch. Follow the iOS prompts that guide you through the pairing process.

Plus members can see the hole's par, handicap and length as well as GPS distances to the center of the green.

Pro members will enjoy accurate distances to all targets, hazards and the front and back of each green, GPS aerial views, score entry and shot tracking.



APPLE WATCH® SERIES 2 PERFORMANCE FEATURES

Apple Watch members with an internal GPS watch - Series 2 and 3 can improve their experience by keeping their watch connected to their iPhone via Bluetooth, while keeping their iPhone in their pocket. We have found this enables quicker GPS updates.

Disabling Bluetooth will allow Golfshot to run independently on the Apple Watch 2 and 3. This is an option if you would like to leave your iPhone behind. For this setup, enable “Watch GPS Always On” under the “GPS, Scoring, Caddie” setting in the iPhone Golfshot app settings. This keeps the GPS active to receive quicker distance updates, please note that constant GPS connection will cause a increased battery drain.

Turn off “Apple Watch Scoring” in settings if you prefer not to score on the Apple Watch. With this setting off will automatically advance to the next hole when you arrive at the next Tee Box.


If you have “Apple Watch Scoring” turned on, when you finish a hole and proceed to the next Tee. Golfshot will automatically advance to the score screen.

GOLFPLAN

Powered by Revolution Golf's extensive and dynamic video library with experts like Martin Chuck, Sean Foley, Andrew Rice, and Don Saladino, Golfplan gives you a front-row seat to the best video


instruction. Up your game with a Golfplan Membership to gain access to over 400 game improving videos from our experts, and more.

Access in-depth and extensive golf instruction series from Golfplan's experts. Tap the In-Depth category to rent each video series for one month for \$9.99.



AWARDS

Earn Awards for your accomplishments on the course with Golfshot. Awards can be earned by improving your game, logging your rounds and tracking your shots. Share Awards after your round by posting them to social media or sending them to your friends.




SETTINGS

About & Support: View our user guide, FAQs, rate and share Golfshot, and speak directly to our Support team in-app.

Equipment: Add and manage your active and retired clubs and other equipment.


Account: Basic settings for all your personal information, like name, email, location, and average to par setup



SETTINGS


GPS, Scoring, Caddie: Contains settings that affect your on-course experience, like GPS refresh rate, custom lay-ups, statistic logging, and Aggressive Caddie, which guides you to use longer distance clubs and cut corners on doglegs.

Sync Regions: Download and update courses to Golfshot by country, state, or province




SELECT FACILITY

After you tap “Start Round” from the home screen you will be brought to the Round Setup screen for the closest course to your location. On the home screen, if you tap “Select Different Facility” you will be taken to the Select Facility screen. Choose facilities nearby to your location, tap “Recent” for recently played facilities, select “Favorites” to choose a course you have saved as a favorite or tap “Browse” to browse and download new ones. Tap the magnifying glass to search for courses manually




ROUND SETUP

Adjust your round settings to turn ON/OFF Calculate Net Scores, change the game type or scoring system for your round.



HOLE LIST

Scroll down to view all holes and their yardage and par information. You can select any hole to start on. If you've played these holes before, other information will appear, like average score, fairway hit percentage, GIR percentage, and putting average. To return to the Hole List, simply tap the back button or swipe left on the GPS screen.




GPS SCREEN

The GPS distances and aerial imagery are displayed on the same screen.


For Pro and Plus members, tap a distance or hazard in the left column and the target will move to that location.

Tap GPS or List on the top of the screen to change the display to your preferred view.



GPS SCREEN

If you hold down and scroll the target to a new area, the manual setting is engaged and you can view your relative distance to any point on the hole.



GOLFSCAPE

To access Golfscape, in the GPS screen, tap on the AR button on the bottom left corner of the screen.

Golfscape is an augmented reality feature that uses the compass and gyroscope on the iPhone to determine direction to the center of the green. As a Pro member, you will receive AR Layups, Hazards and Club Recommendations.



ZOOM


For Pro and Plus members, tap the “+” icon to the right, or double tap the aerial image to zoom in. The target will remain centered as you scroll up or down the hole.



PREVIEW

Utilize the Course Preview Feature and gain access to a new perspective of the course by selecting Preview on the GPS Screen.

Tap the “X” button to return to the GPS Screen.



SHOT TRACKING

Once you've located your ball, tap "At my ball" and you will be taken to the main Tracking screen. Indicate your distance and club used, and whether you hit your target or missed left/right/long/short. Then tap "Save" and your shot is stored.

Select Tracked Shots from the Round Menu to view your saved shots.

×

Tracked Shot

📶



1W
Edit

239
Edit

On Target

Miss Left

Miss Right

Miss Long


Miss Short

Cancel

Save

ROUND MENU

Press the “Menu” button at the bottom of the GPS screen to access the Round Menu. Here you can quickly view your scorecard, go to other holes, view hole details, switch the current GPS view, view tracked shots, access fitness data, take photos, edit golfers, switch to Aggressive Caddie, reload GPS imagery, send updated scorecards or end your round.



HOLE AVERAGES


View and compare you statistical progress for a hole. See how you compare against golfers with the same handicap and all averages.

✕				Hole 12 Averages			
MY AVERAGES							
4.7	52%	34%	2.10	SCORE	FAIRWAYS	GIR	PUTTING
HANDICAP							
4.2	67%	80%	2.00	SCORE	FAIRWAYS	GIR	PUTTING
ALL GOLFERS							
5.1	40%	25%	2.42	SCORE	FAIRWAYS	GIR	PUTTING

SCORING

To access scoring, tap the “Score” button from the GPS screen.


You’ll be taken to Score Summary with a list of all golfers currently playing your round. Tap the golfers name or pencil icon to enter score. After you’ve entered a golfer’s score, you will be brought back to the Score Summary screen where a grey bar under the primary golfer displays a quick average of stats for that particular hole.



SCORING

In Score Entry, you can adjust gross score, putts taken, tee off club, fairway hit, sandshots taken, and any penalties for you and your secondary golfers. For other golfers in your round, you can only enter score and putts by default. To log their full statistics you must make sure that Log Statistics and Log Putts are turned ON for the Secondary golfers in Settings.

Once your score information is inputted, tap the blue "Save" button and your score is stored.



SCORECARD


You can view your scorecard at any time by rotating your phone in the GPS screen (can be turned off in Settings as well). Tap a golfer’s name to view their full statistics, and tap again to return to the list of golfers.

× Rolling Hills Golf Course - Links Blue Tees - 72.3/113										
	1	2	3	4	5	6	7	8	9	OUT
Nathan Henderson	5	4	5	3	5	3	3	6	4	39
	5	4	3	2	6	3	2	3	4	32
PAR	5	4	4	4	4	4	3	5	3	36
PUTTS	2	2	3	1	2	1	2	3	2	19
FAIRWAYS										60%
GIR										82%
SAND SHOTS			1		1			1		3
PENALTY STROKES			1							1

MAXIMIZING BATTERY LIFE

To get the most out of your battery charge follow these tips:

1. Charge it fully before each round
2. Turn off Wi-Fi and Bluetooth
3. Reduce the screen brightness
4. Use Power Save Mode between each shot



SUPPORT RESOURCES

Golfshot provides in-app feedback and support for quicker response times while you're on the course.

Go to Settings > About & Support > Send Us Feedback

